

## PENTEK BFS/BBFS SERIES

### BASIC FILTRATION SYSTEMS

PRE-ASSEMBLED SYSTEMS WHERE SPACE IS LIMITED



Pentair<sup>+</sup> Pentek<sup>+</sup> BFS and BBFS Basic Filtration Systems consist of either two or three filter housings, which are mounted in series, a wall-mounting bracket and hardware.

The BFS-201 features two 3/8" NPT low-profile Slim Line Housings in series for installations where space is limited. The BBFS systems consist of a series of large-capacity 1" NPT #20 Big Blue housings allowing for greater cartridge capacities and higher flow rates. All systems are equipped with a pressure relief button to relieve housing pressure during cartridge changes, and are shipped completely pre-assembled, saving valuable installation time.

All filter housings are manufactured of a durable polypropylene, have excellent chemical resistance and are ideal for many residential, commercial and industrial applications.

#### FEATURES/BENEFITS

Multi-housing systems include wall-mounting bracket and hardware

Available with low-profile Slim Line or large capacity Big Blue housings

All systems are shipped completely pre-assembled, saving valuable installation time

#### MATERIALS OF CONSTRUCTION

Cap – Polypropylene

Housing – Polypropylene

Bracket – Powder coated carbon steel

O-Rings – Buna-N

Maximum Temperature – 100°F (37.8°C)

#### APPLICATIONS

##### Home

Whole House Filtration to Reduce:

Rust Particles

Iron (insoluble)

Sediment

Bad Taste & Odor

Chlorine Taste & Odor

##### Commercial

Deionization

Coalescing

Combination

Sediment/Rust Particles

Bad Taste & Odor

Duplexing

##### Industrial

Step-down Filtration

Circulating Baths

Plating

Batch Treatments

Color Reduction

Organic Reduction

Cooling Towers

Pre RO Filtration

Duplexing

## SPECIFICATIONS AND PERFORMANCE

PART #	MODEL #	MAXIMUM DIMENSIONS	MAXIMUM PRESSURE	FLOW RATE*	HOUSING QUANTITY	HOUSING SIZE
160196	BFS-201	10-1/2" x 5-1/4" x 14" (267 mm x 133 mm x 356 mm)	125 psi (8.62 bar)	up to 10 gpm (37.9 Lpm)	2	3/8" Slim Line
160166	BBFS-22	15-1/4" x 8-1/2" x 26-1/2" (388 mm x 216 mm x 673 mm)	90 psi (6.2 bar)	up to 40 gpm (151.4 Lpm)	2	1" #20 Big Blue
160168	BBFS-222	23-1/4" x 8-1/2" x 26-1/2" (591 mm x 216 mm x 673 mm)	90 psi (6.2 bar)	up to 40 gpm (151.4 Lpm)	3	1" #20 Big Blue

\* Actual flow rate may vary and is dependent on the cartridge used.



### WATER QUALITY SYSTEMS

5730 NORTH GLEN PARK ROAD, MILWAUKEE, WI 53209

P: 262.238.4400 | F: 262.238.4404

WATERPURIFICATION.PENTAIR.COM

CUSTOMER CARE: 800.279.9404 | tech-support@pentair.com

© 2015 Pentair Residential Filtration, LLC. All rights reserved.

†For a detailed list of where Pentair trademarks are registered, please visit [waterpurification.pentair.com](http://waterpurification.pentair.com).

Pentair trademarks and logos are owned by Pentair, Inc. or its affiliates. Third party registered and unregistered trademarks and logos are the property of their respective owners.

310089 REV C MY15