



evoQUA
WATER TECHNOLOGIES



PEARLCOMB AIR DIFFUSER

The Pearlcomb diffuser has been proven in hundreds of installations to be a fine bubble diffuser that requires infrequent cleaning, while maintaining the higher oxygen transfer efficiencies expected from a fine bubble diffuser. These characteristics have been met through the unique technology used to produce the Pearlcomb diffuser. The diffuser tube is made up of minute resin spheres which have been fused together under pressure. This

construction provides a highly uniform, porous material which lends itself for use as an excellent diffuser media. The Pearlcomb diffuser may be mounted on any header manifold having $\frac{3}{4}$ " threaded bosses. Installation is convenient since the diffuser is lightweight and non-abrasive. Pearlcomb diffusers are available in either simplex or duplex continuations.



evoQUA
WATER TECHNOLOGIES

2607 N. Grandview Blvd, Suite 130, Waukesha, Wisconsin 53188

+1 (866) 926-8420 (toll-free)

+1 (978) 614-7233 (toll)

www.evoqua.com

All information presented herein is believed reliable and in accordance with accepted engineering practices. Evoqua makes no warranties as to the completeness of this information. Users are responsible for evaluating individual product suitability for specific applications. Evoqua assumes no liability whatsoever for any special, indirect or consequential damages arising from the sale, resale or misuse of its products.

© 2014 Evoqua Water Technologies LLC

Subject to change without notice

BC-PEARLCOMB-DS-0914